

ELIT-8701 : Temperature Sensor

Datasheet Version: 1 June 2012

Working with Meters and Analyser to measure Temperature



Cost effective, robust Temperature sensor for Lab, Field and light Industrial use, where the sensor head is not submerged

Temperature	Resistance
S°	Ohm
-20.0	1,103,000
-10.0	611,900
0.0	351,000
10.0	207,800
20.0	126,700
25.0	100,000
30.0	79,420
40.0	51,050
50.0	33,590
60.0	22,590
70.0	15,500
80.0	10,840
90.0	7,708
100.0	5,569
P_T Curve for NTC	

Specifications:

- Shaft diameter 3 mm for stainless steel and 3.7mm for ETFE-coated Shaft length 150 mm, Sensor head diameter 16 mm, length 40 mm
- Sensor element Siemens / Matsushita R-T curve-matched Thermistor B57863-S104-F9 (100 kOhm, NTC)
- Accuracy ± 0.2°C between 0.0°C and 70.0°C
- Measuring Range 0.0°C to 100.0°C
- Standard cable length 1 m. Cable lengths of 3 m and 5 m optional.
- Connector: 3.5 mm mono-audio plug.

Options:

When ordering select:

- Stainless steel (instrument grade) or ETFE (Non-stick Teflon-type).
- Cable length: 1 m, 3 m, 5 m.

Measurements:

- Immerse the sensor at minimum 50 mm into the sample.
- If no stirrer is used, then make stirring movements with the sensor (1 turn per second).
- Be aware that there are always temperature layers formed: coolest at the bottom (above 4°C)
- There is always a delay between the actual temperature of the medium and the sensor signal measured.
- The delay follows the exponential curve. The time constant depends on the stirring speed.
- Stainless steel sensors have a time constant of approximately 5 seconds.
- ETFE-coated sensors have a time constant of approximately 15 seconds.

NTC temperature sensors can only be used with instruments which compensate the non-linearity of the Siemens / Matsushita R-T curve-matched Thermistor B57863-S104-F9.



sales@nico2000.net www.nico2000.net